


DeLuxe Wall Console WC-3

Installation instructions

3-function wall console WC-3

- for all Kingstar models
- Impulse, light on/off, "vacation lock"
- Including installation material

Connection



Functions:

The Wall Console model **WC-3** features three functions:

Impulse (lighted) To open and close the garage door.

Light switch To switch internal 40 Watt garage door operator light on and off.
Note: after door movement, the light automatically switches off after approximately 3 minutes.

Vacation lock Vacation lock will be activated by pressing the vacation lock button for approximately 1,5sec. The vacation lock disables any transmitter command; it turns off the internal receiver of garage door operator.

When vacation lock is activated, the LED in command button blinks rapidly.

The WC-3 impulse button does function in 'vacation mode'.

Vacation lock can be de-activated by pressing the vacation lock button again for 1,5sec.